

Model	Position No	Part Number	Description	Qty
WS3174	1	60044621	Screw LH	1
WS3174	2	60044622	13mm Key Chuck &Chuck key	1
WS3174	3	60044623	Output Spindle	1
WS3174	4	60044624	Steel Ball	1
WS3174	5	60044625	Rolling Bearing	1
WS3174	6	60044626	Ring	1
WS3174	7	60044627	Driven Gear	1
WS3174	8	60044628	Spring	1
WS3174	9	60044629	Washer	1
WS3174	10	60044630	Needle Bearing	1
WS3174	11	60044631	Shift Lever	1
WS3174	12	60044632	Press Block	1
WS3174	13	60044633	Center Branket	1
WS3174	14	60044634	Rolling Bearing	1
WS3174	15	60044635	Rotor for 220V	1
WS3174	16	60044636	Rolling Bearing	1
WS3174	17	60044637	Bearing Sleeve	1
WS3174	18	60044638	Stator Locator Pin	2
WS3174	19	60044639	Stator for 220V	1
WS3174	21	60044640	Left/Right Housing	1
WS3174	22	60044641	Carbon Brush (pair) for 220V	1
WS3174	23	60044642	Carbon Holder I	1
WS3174	24	60044643	Spiral Spring	2
WS3174	26	60044644	Forwarder/Reverse Knob	1
WS3174	27	60044645	Switch	1
WS3174	29	60044646	Cable Protector	1
WS3174	30	60044647	Cord & Plug for 220V	1
WS3174	31	60044648	Carbon Holder II	1
WS3174	32	60044649	Self Tapping Screw	4
WS3174	33	60044650	Self Tapping Screw	2
WS3174	34	60044651	Self Tapping Screw	7
WS3174	38	60044652	Side Handle Set	1
WS3174	39	60044653	Depth Ruler	1
WS3174	40	60044654	Oil Shield	1
WS3174	101	60044655	Output Spindle Assembly	1
WS3174	102	60044656	Center Branket Assembly	1
WS3174	103	60044657	Carbon Holder I Assembly	1
WS3174	104	60044658	Carbon Holder II Assembly	1